

EQUIPMENT MAINTENANCE CHECK LIST

Daily Maintenance	
	Clean top and bottom acrylic surfaces after every session with acrylic-safe disinfectant. Wipe down exterior surfaces with mild solution of soap and water (acrylic cleaner generally not recommended) Inspect high pressure filter glass to ensure properly positioned.
Weel	kly Maintenance
	Clean inside acrylic frame to prevent build up of "gunk". Check all fans for proper air flow. Clean both sides of acrylic with Novus #1 (bi weekly if preferred.) Vacuum behind, under, around unit to prevent dust build up.
Mon	thly Maintenance
	Clean reflector panels with soft, damp cloth. Perform thorough cleaning. Wipe down each lamp to remove dust. Check acrylics for scratches and cracks, use Novus #2 and Novus #3 as needed. Check and replace starters as needed. Inspect and replace all filters as needed. Check all electrical connections, at the wall and inside ballast tray (if applicable).
Year	ly Maintenance
	Vacuum dust and debris from all lamps, fans, ballast trays, etc. (Twice yearly if needed.) Clean reflector panels with soft, damp cloth. Perform thorough cleaning. Wipe down each lamp to remove dust. Check acrylics for scratches, cracks, yellowing, replace as needed. Check and replace starters as needed. Check and replace lamps according to usage and lifetime (Twice or more yearly if needed.) Check and replace cylinders (or adjust tension on springs) as needed (twice yearly). Carefully inspect all visible wiring and cords for cracked insulation, frayed ends, etc.

Call the FOUR SEASONS PARTS & TECH SUPPORT TEAM for assistance with:

- The selection and purchase of parts, lamps and acrylics.
- Schematics and manuals for a variety of equipment and brands.
- Setting up and programing your timer.

- Confirming your bed's lamp compatibility.
- Trouble-shooting equipment issues.
- And so much more!



